



Installation Instructions:

1. In lateral conduit installations, wrap bushing sleeve(s) around each cable before wrapping the plug around the bushing(s). Position flange end of bushing toward the conduit openings as shown.
2. At the tops of risers, install the plug first and position the bushing(s) around cable(s) with their flanged end pointed upward. Slide bushing along the cable into the space between the cable and plug.

Note: *Bushing sleeves generally will seal cables or other content 0.005" to 0.008" smaller than the indicated bushing hole diameter dimension, depending upon cable and pipe configuration.*

Tyco Electronics Corporation

8000 Purfoy Road
Fuquay-Varina, NC 27526-3000
Tel.: 919-557-8900
Fax: 919-557-8498
www.tycoelectronics.com

Tyco Electronics and the TE logo are trademarks.

The information given herein, including drawings, illustrations, and charts and schematics which are intended for illustration purposes only, is believed to be reliable. However, Tyco Electronics Corporation makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. Tyco Electronics' obligations shall only be as set forth in Tyco Electronics' Standard Terms and Conditions of Sale for this product and in no case will Tyco Electronics be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of Tyco Electronics products should make their own evaluation to determine the suitability of each such product for the specific application.